Principle of operation

Refrigerant condensers

Principle of operation

Refrigerant vapour (1) circulates through an **evaporative condensing coil (2)**, which is continuously wetted by the **spray system (3)** installed at the top of the condenser. At the same time the **direct driven radial fans (4)**, located at the bottom of the unit, blow ambient **air (5)** upwards through the condenser.
During operation, heat is transferred from the refrigerant to the water, and then to the atmosphere as a portion of the water that evaporates. The condensed vapour then **exits the unit (6)**. The remaining spray water that falls on the **sloping channels (7)** continuously flows into the **sloping sump (8)**, where the water is collected. **Access louvers (9)** prevent water splash-out to the dry section. The spray water **pump (10)** recirculates the water up to the water spray system. The warm saturated **air (11)** leaves the condenser through the drift **eliminators (12)**, which remove water droplets from the air.



Interested in the Polairis condenser? Contact your local BAC representative for more information.

This file has been generated from the BAC website on: 02/05/2024
For more up to date information, visit: https://www.baltimoreaircoil.eu/en/products/Polairis-principle-of-operation